


POWER: This jack should use a 9V effect adapter (internal negative external positive) to power the effect

This knob is a mode switching knob for reverb effects. There are 9 reverb effects to choose from. You can switch different reverb effects by turning this knob.

REVERB: This knob is used to set the intensity of the reverb effect in the reverb effect.

OUTPUT: Connect your amplifier using a 1/4" phone jack here.



COLOR: This knob is used to set the high and low frequency cut-off effect of the reverb effect, that is, by turning the knob, the reverb is biased towards high or low frequencies.

DELAY: This knob is used to set the intensity of the delay effect in the reverb effect.

INPUT: Connect your instrument using a 1/4" phone jack here.

Guitar Effects Pedal Manual


REVERBERRY

Reverb Effects

Weight: 200g (Bare metal).

Dimension: 115mm(L) * 66mm(W) * 35mm(H).

COOLMUSIC



www.coolmusic-tech.com