

**POWER:** This jack should use a 9V effect adapter (internal negative external positive) to power the effect

This knob is a mode switching knob for delay effects. There are 9 delay effects to choose from. You can switch different delay effects by turning this knob.

**DELAY:** This knob is used to set the intensity of the delay effect in the delay effect.

**OUTPUT:** Connect your amplifier using a 1/4" phone jack here.



**FEEDBACK:** This knob is used to set the strength of the feedback signal in the delay effect.

**TIME:** This knob is used to set the length of the delay effect in the delay effect.

**INPUT:** Connect your instrument using a 1/4" phone jack here.


## Guitar Effects Pedal Manual

### ECHOLATION Delay Effects

**Weight:** 200g (Bare metal).

**Dimension:** 115mm(L) \* 66mm(W) \* 35mm(H).

**COOLMUSIC**



[www.coolmusic-tech.com](http://www.coolmusic-tech.com)