


POWER: This jack should use a 9V effect adapter (internal negative external positive) to power the effect

ECHO: This knob is used to adjust the gain of the delay effect. Turning it clockwise can increase the effect intensity, and turning it counterclockwise can reduce or turn off the effect intensity.

OUTPUT: Connect your amplifier using a 1/4" phone jack here.



INTENSE: This knob is used to adjust the delay intensity of the delay effect.

RATE: This knob is used to adjust the delay rate of the delay effect.

INPUT: Connect your instrument using a 1/4" phone jack here.


Guitar Effects Pedal Manual

PLUMP Delay

Weight: 200g (Bare metal).

Dimension: 115mm(L) * 66mm(W) * 35mm(H).

COOLMUSIC



www.coolmusic-tech.com